

## FEATURES AND OPERATION

- Dual LEDs for easy mode (Bypass or Overdrive) identification
- True Bypass – No active or passive components in the signal path.
- LEVEL Control – Sets the output level to the amp for smooth volume transition from Bypass to Overdrive
- TONE Control – For mid frequency control
- DRIVE Control – Sets the Overdrive gain from bluesy, to crunchy, to smooth
- TRIM Control – For high frequency control similar to the Presence control on amplifiers
- Internal 9V Alkaline battery (supplied)
- 9VDC (Negative Center) jack for external supplies.

## WHAT ELSE SHOULD I KNOW?

- The amount of Overdrive distortion will vary depending on your guitar pickups. Single coil pickups have lower output and will tend to be brighter than humbuckers. Humbuckers have higher output, will produce more distortion, and tend to be darker.
- In order to minimize components and maintain faithful tone, there are no components to cancel switch bounce or DC offset. You may notice a slight switch pop in a quiet room.
- External power supplies must be regulated 9VDC


# X-Drive Overdrive Pedal

by



Amplification

520 University Dr.  
Waldorf, MD 20602  
240-222-3830  
www.vvtamps.com



# Thick Smooth Analog OVERDRIVE

Rev 0  
03/09

## LIMITED WARRANTY

This pedal is guaranteed against mechanical and electrical failure to the original owner for ONE YEAR. If you experience a failure, VVT Amps will repair or replace your pedal at our discretion. You must send the pedal to VVT Amps for warranty repairs. Any shipping costs associated with repairs are your responsibility. VVT Amps DOES NOT PAY FOR PARTS OR SERVICE OTHER THAN OUR OWN. A COPY OF THE ORIGINAL SALES RECEIPT IS REQUIRED TO VERIFY YOUR WARRANTY. VVT Amps assumes no responsibility for amplifiers, speakers or other equipment damaged by this pedal. This warranty does not cover, and no liability is assumed, for damage due to: natural disasters, accidents, abuse, loss of parts, lack of reasonable care, incorrect use, or failure to follow supplied instructions. This WARRANTY does not apply to products that have been tampered with, damaged by shipping carriers, reverse engineered, or modified. VVT Amps reserves the right to suspend or terminate the Warranty at our sole discretion, should damage from any of the above limitations and or exclusions be detected upon examination. This warranty is in lieu of all other warranties, expressed or implied. No representative or person is authorized to represent or assume for VVT Amps any liability in connection with the sale or servicing of VVT Amps products. VVT Amps SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. If service is required you may contact VVT Amps at 240-222-3830 or [vvtamps@vvtamps.com](mailto:vvtamps@vvtamps.com). We will respond as soon as possible and make arrangements to repair your pedal. If your unit is out of warranty, VVT Amps will repair your pedal but you will be charged the current RATE for parts and labor.